

Drawer – N Web code – click on the code or enter it in the Product Configurator **DQBMJY**

Planning			
Space requirement in cabinet	Installation dimensions – front – screw-on	Drilling distances – front – EXPANDO EXPANDO T	Installation dimensions – back
<p>* +1 mm if cabinet profile is installed before the cabinet is assembled</p>	<p>FA Front overlay</p> <p>* +1 mm if cabinet profile is installed before the cabinet is assembled</p>	<p>* +1 mm if cabinet profile is installed before the cabinet is assembled</p> <p>** Min. 6 mm for EXPANDO T</p>	

Cutting – 16 mm chipboard		Drilling distances – base	
	<p>LW Internal cabinet width</p> <p>NL Nominal length</p>		
<p>Chipboard back 39 mm</p> <p>LW – 38 mm</p>	<p>LW Internal cabinet width</p> <p>KB Cabinet width</p>		
<p>Base</p> <p>Chipboard back NL – 10 mm</p> <p>Steel back NL – 21 mm</p> <p>LW – 35 mm</p> <p>16</p> <p>8</p> <p>Rebate dimensions</p> <p>38</p>			

Reference pages			
Overview	197	TIP-ON BLUMOTION for LEGRABOX MERIVOBOX TANDEMBOX	394
myLEGRABOX	236		
Fixing system for thin fronts – EXPANDO T	596	TIP-ON for LEGRABOX	404
Assembly recommendation and limitation of liability – EXPANDO T	597		
SERVO-DRIVE for LEGRABOX MERIVOBOX TANDEMBOX	362	CABLOXX	594
		Accessories	244
		Cabinet profile fixing positions	248
		Blum services	602
		More technical details	708
			Assembly, removal and adjustment Short URL www.blum.com/a310

