

Drawer – M Web code – click on the code or enter it in the Product Configurator **DQC2QM**

Planning			
Space requirement in cabinet	Installation dimensions – front – screw-on	Drilling distances – front – INSERTA knock-in	Installation dimensions – back
	<p>FA Front overlay</p>		

Cutting – 16 mm chipboard	
<p>LW Internal cabinet width</p> <p>NL Nominal length</p>	<p>LW Internal cabinet width</p> <p>KB Cabinet width</p>

Reference pages			
Overview	291	Accessories	328
SERVO-DRIVE for LEGRABOX MERIVOBX TANDEMBOX	362	Cabinet profile fixing positions	334
		Blum services	602
		More technical details	708
TIP-ON BLUMOTION for LEGRABOX MERIVOBX TANDEMBOX	394		
ORGA-LINE for TANDEMBOX	554		
CABLOXX	594		
			Assembly, removal and adjustment Short URL www.blum.com/a350

