

Drawer inner drawer – M	Web code	Drawer	DQCL1A
		Inner drawer	DQCNUM

Space requirement in cabinet	Installation dimensions – front – screw-on	Drilling distances – front – EXPANDO knock-in	Installation dimensions – back
<p>* +2 mm with BLUMOTION</p> <p>* +3 mm for inner drawer with BLUMOTION</p>	<p>Drawer</p> <p>FA Front overlay</p> <p>* +2 mm with BLUMOTION</p> <p>* +3 mm for inner drawer with BLUMOTION</p>	<p>Drawer</p> <p>* +2 mm with BLUMOTION</p> <p>* +3 mm for inner drawer with BLUMOTION</p>	

Cutting – 16 mm chipboard

	Chipboard back
71 mm	
LW – 31 mm	
	Base
Drawer	
NL – 2 mm	
Inner drawer	
NL – 18 mm	
LW – 31 mm	
	Front
Inner drawer	
61 mm	
LW – 64 mm	
LW	Internal cabinet width
NL	Nominal length

	<p>LW Internal cabinet width</p> <p>KB Cabinet width</p>	<p>Base – quick assembly version</p>				
			<table border="1"> <thead> <tr> <th></th> <th>X (mm)</th> </tr> </thead> <tbody> <tr> <td>Drawer</td> <td>69</td> </tr> <tr> <td>Inner drawer</td> <td>53</td> </tr> </tbody> </table>		X (mm)	Drawer
	X (mm)					
Drawer	69					
Inner drawer	53					

Reference pages

Overview	339	Assembly, removal and adjustment
Accessories	354	
BLUMOTION for METABOX 320	357	<p>Short URL</p> <p>www.blum.com/a390</p>
Cabinet profile fixing positions	361	
Blum services	602	
More technical details	708	

