

## **Fastmount 10mm Forstner Type Drill – Carbide Tipped**

**Variant code: CT-09**

For use with Standard Profile, Low Profile and Metal ranges. For drilling blind holes into the back of panels.

The Fastmount® multi-award winning system has revolutionized the mounting of panels. Panels can easily be removed and refitted in any sequence time after time.