



## Button-fix™ Safety Cord – Pack of 30

**Variant code: 171-002-4**

The Safety Cord should be used in all applications of Type 2 Button-fix™ where extra safety is required.

On a vertical panel install two Safety Cords, one to each Fix in the top corners. An additional Button is required to capture the loop on the Safety Cord. To remove the panel completely, ease the loop on the Safety Cord off the Button.