



Button-fix™ Type 1 Fix + Button for CSK Wood Screw – Pack of 100

Variant code: 171-001-11

When a panel fitting with proven strength is required, the Type 1 Button-fix™ is the one to use.

Typical uses include:

- Wall & ceiling panels
- Acoustic panels
- Mirror panels
- Shelf units & shop displays
- Upholstered panels & banquette seating

Gallery

