



Button-fix™ Type 3 Fix + Button, Push-on – Pack of 100

Variant code: 171-030-11

The new push-on/pull-off mount for wall and ceiling panels.

Many applications of Type 3 are the same as the versatile Type 1 Button-fix, but where a push-on/pull-off engagement is required. Type 3 Button-fix is ideal for:

- Wall and lightweight ceiling panels
- Boat interiors with irregular-shaped panels
- Acoustic panels including acoustic felt panels
- Upholstered panels, bed headboards and banquette seating
- Panels at the end-of-run or in tight corners on a Button-fix Type 1 installation, where sliding engagement is not possible

Gallery

