



Cooker Switch – Double Plate – Brushed Nickel

Variant code: 34211

Our collection of switches complements our many ironmongery finishes.

Used to control power to a cooker and includes a neon light to show when the switch is on.

Available as a single or double plate.

Supplied with matching SS wood screws.

Property	Value
----------	-------

Finish	Black Nickel
--------	--------------

Width (mm)	146
------------	-----

Depth (mm)	7
------------	---

Range	Cooker
-------	--------

Overall Length (mm)	86
---------------------	----