



Cooker Switch – Single Plate – Brushed Nickel

Variant code: 34212

Our collection of switches complements our many ironmongery finishes.

Used to control power to a cooker and includes a neon light to show when the switch is on.

Available as a single or double plate.

Supplied with matching SS wood screws.

Property	Value
Finish	Black Nickel
Depth (mm)	7
Width (mm)	86
Range	Cooker
Overall Length (mm)	86