



## Cooker Switch – Single Plate – Brushed Nickel

**Variant code: 34212**

Our collection of switches complements our many ironmongery finishes.

Used to control power to a cooker and includes a neon light to show when the switch is on.

Available as a single or double plate.

Supplied with matching SS wood screws.

| Property            | Value        |
|---------------------|--------------|
| Finish              | Black Nickel |
| Depth (mm)          | 7            |
| Width (mm)          | 86           |
| Range               | Cooker       |
| Overall Length (mm) | 86           |