



## **Button-fix™ Type 1 Bonded Fix + Button for CSK Wood Screw - Pack of 100**

**Variant code: 171-017-11**

Type 1 Bonded is widely used for:

- Exhibition and point of sale displays
- Signage
- Transport interior panels
- Wall panelling with thin or lightweight materials
- Laminate sheets of up to 12 mm thick

## Gallery

